



The Battery module supplies power to a sensor, or chain of sensors, operating in the Off-Line mode, and to sensors connected to an RF communication module. The Battery module can be recharged by connecting it to the PC's USB socket via the USB module's USB cable.

BAT-200: This Battery module has a LED and a pushbutton switch. The LED indicates whether the battery is charged enough or not when pressing the pushbutton.

BAT 202: This Battery module has a 3 colors LED: Red when charging the battery; Green when the charging is completed; Orange when current is consumed from the battery.